

## How to convert Btu pressure bases

To convert pressure bases divide the pressure base you are changing to by the pressure base you are currently in and multiple that value against the original gross/dry Btu value.

Example 1:

How to convert 1050.1 gross/dry Btu/scf @14.696 psia & 60 °F to gross/dry Btu/scf @ 14.73 psia & 60 °F.

$$\frac{14.73}{14.696} = 1.0023$$

$$1.0023 \times 1050.1 = 1052.5 \text{ gross/dry Btu/scf @ } 14.73 \text{ \& } 60 \text{ }^\circ\text{F}$$

Example 2:

How to convert 1050.1 gross/dry Btu/scf @ 14.73 psia & 60 ° F to gross/dry Btu/scf @ 14.696 psia & 60 ° F

$$\frac{14.696}{14.73} = 0.9977$$

$$0.9977 \times 1050.1 = 1047.7 \text{ gross/dry Btu/scf @ } 14.696 \text{ psia \& } 60 \text{ }^\circ\text{ F}$$



4170 A Main Pearland, TX 77581 PH: 281-648-1894 FAX: 281-648-1895  
www.dcgpartnership.com  
E-mail: sales@dcgpartnership.com

Chromatographic Reference Materials