

# How to Calculate the Wobbe Index

To calculate the Wobbe index take the Real Gross, Dry, BTU value and divide by the Square root.

For Example:

Real Gross, Dry BTU: 1065  
Specific Gravity: 0.564

$$WI = \frac{BTU}{\sqrt{Sp.G}}$$

$$WI = \frac{1065}{\sqrt{.564}}$$

$$WI = 1418.11$$

